Workmate Trailers 10x7 Hydraulic Tipper Trailer (10x7 HYD TIPPER JLB)

Tandem hydraulic tipping trailer with cage sides and toolbox, built Oct 2023. Plate: ATM 3,500 kg • GTM 3,420 kg • Tare 1,480 kg (max load approx. 2,020 kg) • Tyres 195/70R15C, 32 psi, 100 km/h. Rego 1TZP-198 (WA).

PRE-START CHECKS

- Registration current. Tow vehicle, tow bar and ball rated for 3,500 kg and the ball download.
- Coupling locked on the correct ball; safety chains crossed and attached with rated shackles.
- Brakes: check brake type on the trailer – electric brakes require a working brake controller in the tow vehicle; breakaway system armed and its battery charged.
- Lights, tyres (32 psi as plated), wheel nuts, tailgate and side latches, cage sides secure.
- Tipping pump battery charged; hydraulic hoses not leaking; body sitting down fully on the chassis.

HOW TO OPERATE – BASIC STEPS

1. Load evenly, heavy material forward of the axles; never exceed ATM 3,500 kg. Cover loose loads.
2. Tip only when coupled, on firm level ground, with no overhead powerlines or obstructions above.
3. Keep everyone clear of the rear and sides. Release the tailgate/side latches for the tipping direction.
4. Operate the UP control to raise; stop if the trailer starts to lean. Lower fully with DOWN and re-latch the tailgate/sides.
5. Never drive with the body raised. Never work under a raised body unless it is propped with the safety prop.

KEY HAZARDS

- Trailer tipping over sideways during tipping on uneven/soft ground.
- Crushing under a raised body or between body and chassis.
- Powerline contact when raised.
- Sway/loss of control from overloading or rear-heavy loads; unsecured load.

REQUIRED PPE

- Safety boots, gloves, safety glasses (dust when tipping), hi-vis.

REFUELLING / POWER / CHARGING

- Hydraulic pump runs from the trailer battery – recharge it after use per Foothills Hire instructions. No fuel.

STORAGE & RETURN

- Return empty and swept out, body down, latches closed, controls stowed. Report brake, light or hydraulic faults.
- Return with all accessories supplied. Report any damage, fault or near-miss at return – do not attempt repairs.

MANUFACTURER MANUAL & SDS

- **Manual:** Owner's manual: Manual available on request.
- **Manual:** Manufacturer product range: workmatetrailers.com.au – Hydraulic trailers
- **Manual:** Load restraint: NTC Load Restraint Guide
- **SDS:** Not applicable – no hazardous substances supplied with this item. SDS for any products you use with it (e.g. cement, paints) must be obtained from that product's supplier.

Licence / competency: Driver must hold a current driver's licence appropriate to the combination; comply with WA road rules and the tow vehicle's towing limits.

EMERGENCY: call 000 (Police/Fire/Ambulance) • Poisons Information 13 11 26 • Breakdown or help: see the Contact page at foothillshire.com.au • Site first aider / supervisor: _____

IMPORTANT – READ BEFORE USE. This sheet is a summary only and does not replace the manufacturer's operator manual. The hirer must read, understand and follow the manufacturer's manual and all warning labels before use, and must ensure every operator is trained, competent and – where required – licensed for this equipment and task, as required by the Work Health and Safety Act 2020 (WA) and the Work Health and Safety (General) Regulations 2022 (WA). Do not use equipment that is damaged, untagged or out of inspection date – stop and contact Foothills Hire. Foothills Hire is a business name held by Foothills Industries Group Pty Ltd, ABN 38 688 848 302.