Milwaukee AGV15-125XE – 125 mm 1550 W Angle Grinder

240 V 125 mm (5") angle grinder with variable speed and electronic constant-speed control (see manual for full data).

PRE-START CHECKS

- Electrical test-and-tag label present and in date (AS/NZS 3760); plug, lead and housing undamaged.
- Guard fitted, correct type for the disc (cutting discs need the cutting guard), and adjusted towards the operator.
- Side handle fitted. Disc: 125 mm, M14, rated speed ≥ tool max speed, undamaged and in date; flange and lock nut correct way round.
- Run unloaded for 1 minute with yourself and others out of line of the disc.

HOW TO OPERATE – BASIC STEPS

1. Set speed dial to suit the disc/material. Clamp the workpiece – never hold small work by hand.
2. Hold with both hands; let the tool reach full speed before contacting the work.
3. Don't jam or twist cutting discs; don't restart in a cut. Use spindle lock only when stopped.
4. Wait for the disc to stop before putting the tool down.

KEY HAZARDS

- Kickback from pinched/snagged disc.
- Disc burst; flying sparks and fragments; fire from sparks.
- Electric shock; noise; vibration; dust (silica when cutting masonry).

REQUIRED PPE

- Safety glasses + face shield, hearing protection, leather gloves, long sleeves (non-synthetic), safety boots; P2 respirator for masonry/silica.

REFUELLING / POWER / CHARGING

- Mains 240 V – Plug into an RCD-protected outlet (30 mA) or use a portable RCD; test the RCD button before use. Use only tagged, heavy-duty extension leads, fully unwound, kept out of water and traffic.
- Check for flammable materials before cutting/grinding – hot-work precautions.

STORAGE & RETURN

- Unplug, remove disc if requested, clean dust from vents. Return with key/spanner, side handle and guard.
- Return with all accessories supplied. Report any damage, fault or near-miss at return – do not attempt repairs.

MANUFACTURER MANUAL & SDS

- **Manual:** Milwaukee AGV15-125XE manual: milwaukeetool.com.au – AGV15-125XE manual (PDF)
- **SDS:** Not applicable – no hazardous substances supplied with this item. SDS for any products you use with it (e.g. cement, paints) must be obtained from that product's supplier.

Licence / competency: No licence required. Users must be competent; hot-work permits may be required on site.

EMERGENCY: call 000 (Police/Fire/Ambulance) • Poisons Information 13 11 26 • Breakdown or help: see the Contact page at foothillshire.com.au • Site first aider / supervisor: _____

IMPORTANT – READ BEFORE USE. This sheet is a summary only and does not replace the manufacturer's operator manual. The hirer must read, understand and follow the manufacturer's manual and all warning labels before use, and must ensure every operator is trained, competent and – where required – licensed for this equipment and task, as required by the Work Health and Safety Act 2020 (WA) and the Work Health and Safety (General) Regulations 2022 (WA). Do not use equipment that is damaged, untagged or out of inspection date – stop and contact Foothills Hire. Foothills Hire is a business name held by Foothills Industries Group Pty Ltd, ABN 38 688 848 302.