Stanley Spirit Level – 1800 mm

1800 mm aluminium spirit level (Stanley). Model number not recorded.

PRE-START CHECKS

- Vials intact, liquid clear, no cracks or leaks; frame straight, not dented or twisted; end caps fitted.
- Accuracy check: place on a stable, near-level surface and read the bubble; turn the level end-for-end in the same spot – the bubble should read the same. If not, do not use; return to Foothills Hire.

HOW TO OPERATE – BASIC STEPS

1. Place the level on a clean surface free of debris.
2. Read the vial square-on (eye level with the vial) for horizontal; use the plumb vials for vertical.
3. For long spans, use a straight edge or a longer level rather than stepping the level.
4. Do not use the level as a lever, hammer or straight edge for cutting.

KEY HAZARDS

- Minor manual handling; dropping on feet.
- Aluminium is conductive – keep clear of live electrical parts and overhead powerlines.
- Sharp edges on damaged frames.

REQUIRED PPE

- As required for the job site (e.g. safety boots, gloves).

REFUELLING / POWER / CHARGING

- Not applicable – hand tool.

STORAGE & RETURN

- Wipe clean (remove concrete/mortar before it sets) and return dry. Store flat; do not drop – drops can affect accuracy.
- Return with all accessories supplied. Report any damage, fault or near-miss at return – do not attempt repairs.

MANUFACTURER MANUAL & SDS

- **Manual:** Manual available on request.
- **SDS:** Not applicable – no hazardous substances supplied with this item. SDS for any products you use with it (e.g. cement, paints) must be obtained from that product's supplier.

Licence / competency: No licence required.

EMERGENCY: call 000 (Police/Fire/Ambulance) • Poisons Information 13 11 26 • Breakdown or help: see the Contact page at foothillshire.com.au • Site first aider / supervisor: _____

IMPORTANT – READ BEFORE USE. This sheet is a summary only and does not replace the manufacturer's operator manual. The hirer must read, understand and follow the manufacturer's manual and all warning labels before use, and must ensure every operator is trained, competent and – where required – licensed for this equipment and task, as required by the Work Health and Safety Act 2020 (WA) and the Work Health and Safety (General) Regulations 2022 (WA). Do not use equipment that is damaged, untagged or out of inspection date – stop and contact Foothills Hire. Foothills Hire is a business name held by Foothills Industries Group Pty Ltd, ABN 38 688 848 302.